

Figure 10E. Fully Housed 4x
Used for rough openings, jack posts under headers, and corners where extra
area or heavier bearing strength is needed

